How to clean carpet

with the Britex Deep Cleaning Machine

1 Firstly, set up your Britex Machine for carpet cleaning.

Pull back the brass sleeve on the end of the of the black solution hose and attach it to the carpet wand underneath the trigger until it locks into place. Release the sleeve.

2 Pull back the smaller brass end of the black solution hose and insert it into the connection under the button at the front of the machine under the vacuum and pump switches.

3 Connect one end of the larger vacuum hose to the Tank A dome lid, and the other end to the carpet wand tube just above the wand trigger.

4 Remove dome lid from Tank A.

Add 2 capfuls of Britex defoamer. Replace the dome lid securely.

5 Fill Tank B with 9L of hot water, ensuring the water level does not go above the filter.

Add 3 capfuls of Britex Carpet Cleaning Solution.

6 Plug the machine into your power point.

Turn both vacuum and pump buttons on.

Place the floor wand face-down onto the carpet.

7 Hold in the trigger on the wand to apply water and solution to the carpet, whilst moving the head forward over the carpet.

Release the trigger, and draw the floor wand back to vacuum over the dampened area to extract the water and dirt.

Note: Apply a light spray – do not saturate the carpet.

Repeat this process over stained areas.

8 If tank B is empty, refill with 3 capfuls of Britex Carpet Cleaning solution and 9 litres of hot tap water.

9 Periodically check tank A and discard the dirty water when required. Refill Tank A with 2 capfuls of Britex Defoamer if you are continuing to clean.

When you are finished cleaning

Release any unused solution from Tank B using the tap at the back of the machine and empty out the dirty water from Tank A. Rinse out the dome lid and filter. Clean the machine thoroughly before returning it to store.

STILL NEED HELP?

Watch our how-to videos at Britex.com/support

OR call us 7 days a week on 1800 804 973.

Call our Helpline on 1800 804 973 for assistance.

www.britex.com