

How to clean upholstery using the Britex Deep Cleaning Machine



Live clean, love Britex.

- 1** Firstly set up the Britex machine for upholstery cleaning. Pull the brass sleeve on the end of the black solution hose and attach it to the upholstery wand underneath the trigger until it locks into place, release the sleeve.



- 2** Pull back the smaller brass end of the solution hose and insert into the connection under the button at the front of the machine under the vacuum and pump switches.



- 3** Connect one end of the larger vacuum hose to the Tank A dome lid, and the other end to the upholstery wand tube just above the trigger.



Call our Helpline on 1800 804 973 for assistance.

www.britex.com

- 4** Remove dome lid from Tank A, add 2 capfuls of Britex defoamer. Replace the dome lid securely.



- 5** Fill Tank B with 9L of hot water, ensuring the water level does not go above the filter. Add 4 capfuls of Britex Upholstery Cleaning Solution.



- 6** Plug the machine into your power point.

Turn both the vacuum and pump buttons on.

Hold in the upholstery wand trigger to apply water and solution to upholstery, whilst moving the head forward. Release the trigger, and draw upholstery wand back to vacuum over dampened area to extract water and dirt. Repeat this process over stained areas.

Note: Apply a light spray as to not over saturate fabric

Extra passes using the vacuum without spraying water will speed up the drying process.



- 7** Periodically check tank A and discard the dirty water when required. Refill Tank A with 2 capfuls of Britex Defoamer if you are continuing to clean.

When you are finished cleaning

Release any unused solution from Tank B using the tap at the back of the machine and empty out the dirty water from Tank A. Rinse out the dome lid and filter. Clean the machine thoroughly before returning it to store.

For cleaning instructions go to Britex.com/support

Call our Helpline on 1800 804 973 for assistance.

www.britex.com