




HOW TO CLEAN UPHOLSTERY

Using the Britex Deep Cleaning Machine

1

Firstly, follow the 'HOW TO SET UP THE MACHINE' instruction guide.


NOTE Always check the care instructions of upholstery and spot clean an inconspicuous area of your carpet first to check for colourfastness



2

Fill TANK B with 9L of hot tap water (the water should be level with the filter)

NOTE Do not use boiling water




3

Add the required amount of BRITEX UPHOLSTERY CLEANING SOLUTION by following the back of pack directions.



4

Plug the machine into a power point, turn on both the PUMP & VAC button.



- 5 To use the Britex upholstery tool, move the head forwards and backwards slowly over the upholstery or stairs.



- 6 Hold in the spray lever on the tool handle to apply water and solution. Spray on the forward motion. For every pass where you spray water, use 2-3 passes without spraying to extract the water and dirt. Repeat process over stained areas.

NOTE To stop spraying simply release the trigger
DO NOT saturate.




- 7 If TANK B is empty, refill as per Step 2 & 3. Empty TANK A of dirty water down the laundry sink and replace back into the machine and continue.



- 8 When you are finished cleaning empty the dirty water from TANK A and release any unused water from TANK B using the tap at the back of the machine.

Clean the machine thoroughly including the wands before returning to the store.



For deep and stubborn stains pre treat upholstery with BRITEX SPOT N STAIN.



Still need assistance?
Watch our how-to-videos at britex.com/
OR call our customer service team
1800 804 973

Open from 9.00am – 5.00pm Weekdays
10.00am–5.00pm Weekends
Closed Good Friday, Christmas Day and Boxing Day