




# HOW TO CLEAN CARPET & RUGS

## Using the Britex Deep Cleaning Machine

1

Firstly, follow the 'HOW TO SET UP THE MACHINE' instruction guide.

**NOTE** Always check the care instructions of your carpet and rugs and spot clean an inconspicuous area of your carpet first to check for colourfastness



2

Fill TANK B with 9L of hot tap water (the water should be level with the filter)

**NOTE** Do not use boiling water



3

Add the required amount of BRITEX CARPET CLEANING SOLUTION by following the back of pack directions (approximately 75ml to every 9L of water).



4

Plug the machine into a power point, turn on both the PUMP & VAC button.





## HOW TO CLEAN CARPET & RUGS

5

Use the Britex carpet wand like you would a vacuum cleaner, moving the head forwards and backwards slowly over the carpet.



6

Hold in the spray lever on the wand handle to apply water and solution to the carpet.

Spray on the forward motion. For every pass where you spray water, use 2-3 passes without spraying to extract the water and dirt from the carpet. Repeat process over stained areas.

**NOTE** To stop spraying simply release the trigger DO NOT saturate your carpet



7

If TANK B is empty, refill as per Step 2 & 3.

Empty TANK A of dirty water down the laundry sink and replace back into the machine and continue.





## HOW TO CLEAN CARPET & RUGS

8

When you are finished cleaning empty the dirty water from TANK A and release any unused water from TANK B using the tap at the back of the machine.



Clean the machine thoroughly including the wands before returning to the store.

For deep and stubborn stains pre treat carpets and rugs with BRITEX SPOT 'N' STAIN or BRITEX URINE REMOVER.



**Need help?**

**Watch our how-to-videos at [britex.com/](http://britex.com/)**

**OR call our Customer Service Team**

**1800 804 973**

Open from 9.00am – 5.00pm Weekdays

10.00am – 5.00pm Weekends

Closed Good Friday, Christmas Day and Boxing Day

